



Phase Plug Support

INTRODUCTION
LICENSE AGREEMENT AND WARRANTY
CUSTOMER SUPPORT
INSTALLATION
INTERFACE OVERVIEW
MENU BAR
TAB CONTROL
UNITS AND PREFIXES
SAVED DATA FORMAT
REFERENCES

© Copyright 2004-2024 by SpeakerLAB Srl
All Rights Reserved
Printed in Italy, May 2024

IBM is a registered trademark of International Business Machines Corporation.
Windows is a registered trademark of Microsoft Corporation.

INTRODUCTION

ABOUT THIS MANUAL

This User's Manual explains the PPS software version 1.0.0.

WHAT THIS USER MANUAL DOES COVER

The PPS software is a tool to fast design 2D Phase Plug. There are several documents on many of the topics that PPS handles. This User Manual is intended not to explain Phase Plug theory, this issue is left to the reader to explore through the available literature, but only as a guide to allow the user to quickly become efficient with the user interface PPS software.

LICENSE AGREEMENT AND WARRANTY

THANKS

Thank you for purchasing your PPS software. We hope that your experiences using PPS will be both productive and satisfying.

SpeakerLAB's WARRANTY

SpeakerLAB warrants to the original licensee that the disk(s) and or electronic key(s) on which the program is recorded will be free from defects in materials and workmanship under normal use for a period of ninety (90) days from the date of purchase. If failure of the product components has resulted from accident, abuse, or misapplication of the product, then SpeakerLAB or third party licensors shall have no responsibility to replace the disk(s) or key(s) under this limited warranty.

WARNINGS AND LIMITATIONS OF LIABILITY

SpeakerLAB will not assume liability for damage or injury due to user servicing or misuse of our product. SpeakerLAB will not assume liability for the recovery of lost programs or data. The user must assume responsibility for the quality, performance and the fitness of SpeakerLAB software and hardware for use in professional production activities. In addition to the foregoing, you should recognize that all complex software systems and their documentation contain errors and omissions. SpeakerLAB, its distributors, and dealers shall not be responsible under any circumstances for providing information on or corrections to errors and omissions discovered at any time in the product, whether or not they are aware of the errors or omissions. SpeakerLAB does not recommend the use of this product in applications in which errors or omissions could result in loss of life, injury, or other significant loss. You may not: (a) distribute copies of the program or the documentation to others, (b) lease, rent, grant sublicenses, or other rights to the program, (c) provide use of the program in a computer service business, network, time-sharing multiple CPU, virtual machine or multiple users arrangement without the prior written consent of SpeakerLAB, (d) translate or otherwise alter the program or related documentation without the prior written consent of SpeakerLAB.

This license agreement shall be governed by the laws of the state of Italy and shall inure to the benefit of SpeakerLAB, its successors, administrators, heirs and assigns or third party licensors. For further detail of software license agreement read License.pdf file.

CUSTOMER SUPPORT

SpeakerLAB provides detailed electronic manuals and on-line help within the program as the primary source for user information and assistance regarding the use of this product. If these sources do not contain the answers to your questions, for technical problems, bug reports, or suggestions for future software enhancements contact SpeakerLAB via any of the following methods:

website: www.speakerlab.it
e-mail: info@speakerlab.it

Technical support is free at this time; however, we reserve the right to charge for this service in the future as conditions, overhead, and support personnel requirements dictate.

INSTALLATION

SYSTEM REQUIREMENTS

PPS software is an extremely intensive numerical application. The program contains hundreds of numerical mathematics algorithms, some of which are extremely large and place very high demands on the CPU's floating-point performance. PPS software requires a full 32 bit operating system and can be installed in any personal computer with the following minimum system requirements:

- Pentium IV processor
- 500 MB RAM
- Mouse and Keyboard
- 300 MB free HDD space
- 800 x 600 resolution video adapters
- Microsoft Windows XP, 7, 8, 8.1, 10
- Adobe Acrobat Reader

SOFTWARE INSTALLATION

- Delete all previous installations, included Demo Version
- Place the distribution CD into your CD-ROM drive
- If the CD does not AutoRun, locate and run the Phase Plug Support.exe file
- Follow the instructions on the screen
- After installation Shutdown and Restart OS
- Run PPS from relative link on desktop or from SpeakerLAB folder on Start Menu
- At first launch PPS create a code on desktop
- Send this code to the factory: copy or attach it in the e-mail info@speakerlab.it

INTERFACE OVERVIEW

MENU BAR

TAB CONTROL

The interface features a menu bar with 'File', 'Edit', 'Number of Rings', 'Delimiter', and 'Help'. Below it is a tab control with 'DOMES & RINGS GEOMETRY', 'COMPRESSION RATIO', 'RING WIDTH', and 'PHASE PLUG PROFILE'. The 'DOMES & RINGS GEOMETRY' tab is active, displaying various parameters for dome and rings geometry.

Dome Dimension

Dome OD	Dome Thick
51.257 mm	0.1250 mm
Dome Radius	PP Radius
31.314 mm	30.651 mm
Dome Angle	Dome Arc
109.858 deg	60.04 mm
H_Dome	H_PP
13.321 mm	12.659 mm

Rings Position

A(n)	B(n)	Alpha (n)
0.079 mm	2.193 mm	4.104 deg
0.413 mm	5.016 mm	9.42 deg
1.012 mm	7.813 mm	14.767 deg
1.871 mm	10.544 mm	20.121 deg
2.981 mm	13.185 mm	25.478 deg
4.333 mm	15.712 mm	30.837 deg
5.916 mm	18.101 mm	36.196 deg
7.715 mm	20.332 mm	41.556 deg
9.714 mm	22.386 mm	46.915 deg
11.897 mm	24.244 mm	52.276 deg

HF Cutoff
3579 Hz

Cavity Width
0.6000 mm

1th Resonant Frequency of Cavity
3946 Hz

The graph shows the Minor Axis (0 to 26) versus the Major Axis (0 to 25.63). The cavity profile is a blue shaded area bounded by a curve. The 1st Resonant Frequency of Cavity is 3946 Hz.

MENU BAR

File

Open **Ctrl+O**

Select a *.DAT file to read and open a saved project from “Horn db” database

Exit **Ctrl+Q**

Quit and exit from Horn.ell.a. After you select Exit the software ask you a confirmation of this action



Edit

Cut **Ctrl+X**


Cut data from clipboard

Copy **Ctrl+C**

Copy data from clipboard


Paste **Ctrl+V**

Paste data into clipboard



Number of Rings

Number of phase plug rings.
If NR= 1 there is a single
channel. Max NR= 10.



Delimiter

TAB

Saved data separated by TAB

Comma

Saved data separated by comma

Dot


Saved data separated by dot

Space

Saved data separated by space

Custom

Saved data separated by a free
custom delimiter



Help

Contest Help

Instantaneous on-line information on mouse passage

Phase Plug Support Help

Open this pdf manual

Web Resources


Open factory web site on a default internet browser

About

Open product information



TAB CONTROL




Cavity width is the volume area between Dome and Phase Plug. In other words, this gap is the distance between the inner diameter of the dome and the outer diameter of phase plug.

In this graph is visible the axis symmetric half section profile of **Dome** (pink line) and filled **Phase Plug** (blue area).

DOME & RINGS GEOMETRY

In the first TAB you can edit the dome variables (red displays). In the central table Phase Plug Support resolve the axis position and Alpha angle of each selected rings.




Dome Dimension

Dome OD	51.257 mm	Dome Thick	0.1250 mm
Dome Radius	31.314 mm	PP Radius	30.651 mm
Dome Angle	109.858 deg	Dome Arc	60.04 mm
H_Dome	13.321 mm	H_PP	12.659 mm
HF Cutoff			


Rings Position

A(n)	B(n)	Alpha (n)
0.079 mm	2.193 mm	4.104 deg
0.413 mm	5.016 mm	9.42 deg
1.012 mm	7.813 mm	14.767 deg
1.871 mm	10.544 mm	20.121 deg
2.981 mm	13.185 mm	25.478 deg
4.333 mm	15.712 mm	30.837 deg
5.916 mm	18.101 mm	36.196 deg
7.715 mm	20.332 mm	41.556 deg
9.714 mm	22.386 mm	46.915 deg
11.897 mm	24.244 mm	52.276 deg



Moving yellow point **cursor** is possible to set the required **Phase Plug Length**. By this way the designer has the channels path on left side and the compression driver exit on right side (usually integrated in the pole plate). Positioning the cursor on maximum path length it's possible to design a full path phase plug.

In the **Half Circular Profile** graph there is the half section profile of the total volume area of phase plug.




COMPRESSION RATIO

In the second TAB you can edit channels opening and path profile to adjust the required Compression Ratio.

Compression Ratio is the ratio of the projection of radiating membrane area in the direction of vibration to the area of the surface of compression cavity.


Environment information are the environment average working temperature and humidity of the internal path of compression driver. This information is very important to obtain a high-quality final result of expected low frequency response. In ex. for **High Fidelity** applications a temperature values range could be about 310÷330 K, for **Professional** applications a range about 330÷360 K.

Half Circular Profile



Phase Plug length
11.536 mm

Channels side ← ||| ||| → Pole Plate side



Flare Constant

is the degree of hyperbolic expansion.
 If Flare Constant= 0 the expansion is Catenoid.
 If Flare Constant= 1 the expansion is purely Exponential.
 If Flare Constant< 1 the expansion is Hyperbolic Cosine.
 If Flare Constant> 1 the expansion is Hyperbolic Sine.
 If Flare Constant tends to $+\infty$ the expansion is Conic.

LF Cut-Off

is the lower crossover frequency

Internal Progression & Compression

Path length	17.000 mm	Throat area	147.958 mm ²
Driver exit OD	25.4 mm	Mouth Area	506.707 mm ²
LF Cutoff	2000 Hz	Compression Ratio	13.946
Flare Constant	1.0		
Sample X	28		

Sample X

Samples X is the quantity of segments to split the total phase plug length.

Target throat area is obtained in COMPRESSION RATIO TAB.
 To achieve target Compression Ratio value setting Width of Ring (n) array,
 to obtain a value of Rings throat area next to Target throat area.

An/A1	Wn/W1	Width of Ring (n) mm	Circular Throat Area Ring (n) mm ²	% Ring (n) width on total throat area
2.328	1.014	0.2	2.756	1.863
3.658	1.016	0.211	6.651	4.495
4.987	1.017	0.213	10.456	7.067
6.317	1.018	0.222	14.708	9.941
7.647	1.018	0.231	19.137	12.934
8.978	1.018	0.262	25.864	17.481
10.307	1.018	0.278	31.617	21.369
11.639	1.018	0.298	38.07	25.73
12.954	1.017	0.312	43.884	29.66
		0.341	51.944	35.107

Target throat area
 147.96 mm²

Rings throat area
 245.09 mm²

Rings mouth area
 325.434 mm²

Ring Width ratio

Ring Area ratio

RING WIDTH

In the third TAB the goal is to set the required rings width to achieve target Compression Ratio.

If you need to build a phase plug with Radial slots, consider this data and convert it into radial throats.

Sum of the rings exit area

When you terminate the project and set all parameters, you can build 2D Graph.

Width of Ring (n)

Setting different **Width of Ring (n)** values you can modify the **Rings throat area**.

There are 3 techniques to set the rings width array:

- **Manual Setting**
- **Calculate Bessel Function**
- **Optimize Bessel Area**

NOTE: the calculus is done in cylindrical coordinates.

Calculate Bessel Function

Set only the first value of ring width and push **Calculate Bessel Function** button to obtain the other values with Bessel Function. The default first value is 1 mm.

Optimize Bessel Area

Push **Optimize Bessel Area** button to start the automatic fitting process to set all rings width values. This process finish when the value of **Rings throat area** reaches the value of **Target throat area**.

Calculate
Bessel Function

Optimize
Bessel Area

Width of Ring (n)

▲▼	0.2	mm
▲▼	0.211	mm
▲▼	0.213	mm
▲▼	0.222	mm
▲▼	0.231	mm
▲▼	0.262	mm
▲▼	0.278	mm
▲▼	0.298	mm
▲▼	0.312	mm
▲▼	0.341	mm

Manual Setting

Possibility to free edit all single display values.

This technique is useful in case of external optimization of rings width; coming for example from a FEA simulation, or from other analytical solutions (using Legendre function in spherical coordinates) or experimental study.



To modify phase plug path:

- 1) Select channel with **Cursor Control**
- 2) Move cursor with mouse along the channel profile and positioning cursor on the requested point
- 3) Press space bar to edit the point
- 4) Drag the selecting point on new position on the space
- 5) Press space bar to drop the point

PP Side

selecting the membrane side for the phase plug position (convex or concave side)

Select channel to measure & edit



PHASE PLUG PROFILE

In the fourth TAB you can visualize the half section of phase plug progression. It's possible to edit every point position to modify the required phase plug shape.

Arrow buttons for selecting or modifying the cursor position. As a precise alternative of mouse.

Outer length of channel (upper yellow line) where is the active cursor.

Median length of channel (red line) where is the active cursor.


Inner length of channel (lower yellow line) where is the active cursor.

UNITS AND PREFIXES

PPS recognizes both **SI units** and units from other systems of measurement. It's possible to directly convert unit string writing on the unit box your preferred unit.

Some length unit examples are **m, cm, mm, in, ft**, etc.

Some temperature unit examples are **K, degC, degF**, etc



PPS recognizes also a prefix to a unit. To apply a preferred prefix selects the prefix in this listbox.

SI prefixes

- y yocto (10^{-24})
- z zepto (10^{-21})
- a atto (10^{-18})
- f femto (10^{-15})
- p pico (10^{-12})
- n nano (10^{-9})
- u micro (10^{-6})
- m milli (10^{-3})
- c centi (10^{-2})
- da deka (10^1)
- h hecto (10^2)
- k kilo (10^3)
- M mega (10^6)
- G giga (10^9)
- T tera (10^{12})
- P peta (10^{15})
- E exa (10^{18})
- Z zetta (10^{21})
- Y yotta (10^{24})

SAVED DATA FORMAT

Saved Data

Inside Phase Plug Support.exe directory path, the software automatically creates the database **Phase Plug db** and putting inside all saved designs.

When saving the design PPS generates a directory with the name you selected.

If you don't type any name for a design, PPS save the files in the **Last Routed** directory. This operation is useful in case of forget to type a name, or due to a fortuity button pressing.

Each directory inside **Phase Plug db** appears with this style


$0 \div N$ are 2D design text files, with this format:
X,Y,Z

$N = (\text{Number of phase plug rings} \times 2) - 1$
 $N = \text{odd numbers} \rightarrow \text{inner channels profile}$
 $N = \text{even numbers} \rightarrow \text{outer channels profile}$

(X,Y,Z are floating-point numbers by 6 fractional format digits. In all cases $Z=0$)

Data is a .DAT file, it's required to reopen the project with all saved configuration.

Exit (if $\neq 0$) is a 2D text file of the compression driver exit profile (usually integrated in the pole plate).



In this example:
a phase plug with 7 rings

inner first channel profile

outer first channel profile

inner second channel profile

.
. .
. .
. .
. .

